
1						ł
				0501—RADIATOR		
G50	3-0131549	FM-GPW-8100-A	WO-A-1215	CAP, filler, radiator, assembly (AC-846709)	1	.407
			WO-A-6942	CAP, filler, radiator, assembly (Note 1)	1	
H10	06-0103647	FM-9N-8115	WO-A-1126	COCK, drain, radiator (1/4 in.) (WH-145-A) (EAT-IE-1212)	1	.083
	Ţ	FM-GPW-8005		CORE, radiator	1	13.15
3320		FM-GPW-8005-A	WO-A-1214	CORE, radiator, w/TANK and SHROUD, assembly	1]
		FM-355762-S7		BOLT, carriage, rd-hd., sq-nk., S., cd-pltd., $\frac{1}{16}$ -20NF-2 x 1 $\frac{1}{2}$ (FORD only)	2	.021
l		FM-34084-S7	WO-A-1546	NUT, reg., hex., s-fin., S., cd-pltd., 1/16-20NF-2	4	
		FM-34708-S7	WO-A-1547	WASHER, plain, S., cd-pltd., $\frac{1}{16}$ in.	2	[
Ī		FM-356314-S7	WO-53027	WASHER, lock, internal-external tooth, S., cd-pltd., 7/16 in	2	
ł			WO-A-6941	CORE, radiator, w/SHROUD, assembly (Note 1)	1	
G103	3-1593621	FM-K-7129-B	WO-A-1216	GASKET, radiator filler cap (AC-846732)	. 1	.016
•	Ì	FM-GPW-8133	WO-A-1217	ROD, brace, radiator core	1	.163
	1-4167560	FM-33798-S7	WO-A-1532	NUT, reg., hex., s-fin., S., cd-pltd., 5/6-24NF-2 (GM-103025)	3	
H00	1-7025711	FM-34806-S7	WO-51833	WASHER, lock, reg., S., cd-pltd., 5/16 in.	3	
		FM-GPW-8125-A	WO-A-4413	SHIM, radiator core to support bracket	2	.006
				0501C—SURGE TANK		
•	İ			(Only for Vehicles Modified by FSMWO-G503-W1)		
]	•	WO-A-6947	CLAMP, radiator surge tank connecting hose (5/8 in.)	4	
	ĺ		WO-A-6946	HOSE, connecting, radiator surge tank tube	2	
1	,	!	WO-A-11121	PLATE, tapping, radiator surge tank	2	
	İ					
	•			-,		

Figure Number		Official Stock Number	Piece Mark or Part Number		ITEM		Unit Price
<u>ن</u>		Number	Ford No.	Willys No.		Unit Assy.	
	Col. 1	Col. 2	Col. 3	Col. 4	Col. 5	Col. 6	Col. 7
					0501C-SURGE TANK (Cont'd) (Only for Vehicles Modified by FSMWO-G503-W1)	.*	
i)		H001-7025685 H101-0121668		WO-A-6949 WO-52161 WO-52468 WO-53058 WO-A-11176 WO-52168 WO-53195 WO-52217 WO-52031 WO-50937 WO-A-6933 WO-A-6945	STRAP, mounting, radiator surge tank NUT, mach., screw, hex., S., ½-28NF-2 SCREW, mach., hex-hd., S., ½-28NF-2 x ½ WASHER, lock, reg., S., ¼ in. SHIELD, radiator surge tank, assembly BOLT, hex-hd., S., ½-20NC-2 x ½ BOLT, hex-hd., S., ½-20NC-2 x 1½ (for tapping plates) NUT, reg., hex., S., ½-20NC-2 WASHER, lock, reg., S., ¼ in. WASHER, plain, S., ¼ in. TANK, surge, radiator, assembly TUBE, radiator surge tank	2 4 4 1 2 2 2 4 6 1	
					0502—THERMOSTAT		,
	01-4 01-4	3320-GPW-8578 G503-0400093	FM-GPW-8578 FM-GPW-8575	WO-639651 WO-637646	RETAINER, thermostat THERMOSTAT, assembly (HR-3108628)	1	.0239 .424
	s s				0503—WATER PUMP		!
	01-4, 05-1	H012-0900105	FM-GPW-8530-A FM-GPW-8530	WO-636297	BEARING, water pump, w/SHAFT, assembly, FM-GPW-18515-B (superseded by BEARING, assembly, FM-GPW-8530, WO-636297) BEARING, water pump, w/SHAFT, assembly (double row, annular) (ND-885141) (MRC-D2-13567) (HO-88541) (also in KIT, FM-GPW-18515-B, WO-A-6839) (supersedes BEARING, assembly, FM-GPW-8530-A)	1	
	05-1 05-1	3320-GPW-8505 G503-0194016	FM-GPW-8548 FM-GPW-8505 FM-GPW-8543	WO-640032 WO-637052 WO-637053	BELLOWS, water pump seal. BODY, water pump. GASKET, water pump to cylinder block (also in KIT, FM-GPW-18515-B, WO-A-6839 and GASKET SET, FM-GPW-18387, WO-A-1536).	1 1 1	.0098
	01-4, 05-1	3320-GPW-8512	FM-GPW-8512 FM-GPW-18515	WO-639993 WO-A-1539	IMPELLER, water pump KIT, repair, water pump (superseded by KIT, FM-GPW-18515-B, WO-A-6839) KIT, repair, water pump (superseded by KIT, FM-GPW-18515-B, WO-A-6839)	1 1 1	.733 1.124



Key	Part Name	Ford Part No.	Willys Part No.	Group No.
Α	PULLEY	FM-GPW-8509-A	WO-636299	0503A
. в	BEARING, w/SHAFT, assembly.	FM-GPW-8530	,.WO-636297	0503
C	SPRING	FM-GPW-8 <i>57</i> 6	., WO-636298	0503
D	BODY	FM-GPW-8505	WO-637052	0503
	WASHER			
	SEAL, assembly			
G	IMPELLER	FM-GPW-8512	WO-639993	0503
Н	GASKET	FM-GPW-8543	WO-637053	0503

G-50	Figure Number	Official Stock	Piece Mark or Part Number		ITEM	Quant. Reqd.	Unit Price
ŭ		Number	Ford No.	Willys No.			
	Col. 1	Col. 2	Col. 3	Col. 4	Col. 5	Col. 6	Col. 7
	-						
		_			0503—WATER PUMP (Cont'd)		
		3320-GWP-18515-B	FM-GPW-18515-B	WO-A-6839	KIT, repair, water pump (supersedes KIT, FM-GPW-18515, WO-A-1539)	1	1.124
			FM-GPW-8530	WO-636297	1 BEARING, w/SHAFT, assembly		
			FM-GPW-8543	WO-637053	1 GASKET, pump to block		
		1	FM-GPW-8524-A	WO-640031	1 SEAL, assembly		
			FM-GPW-8576	WO-636298	1 SPRING, retaining, bearing		
		İ	FM-GPW-8557-A	WO-640034	1 WASHER, seal)		
			FM-GPW-18515-C	WO-A-8774	KIT, repair, water pump seal(Consists of:	1	
			FM-GPW-8543	WO-637053	1 GASKET, pump to block		
			FM-GPW-8524-A	WO-640031	1 SEAL, assembly		
j			FM-GPW-8576	WO-636298	1 SPRING, retaining, bearing		
		0.500.0045005	FM-GPW-8557-A	WO-640034	1 WASHER, seal)	ı	
		G503-0345896	FM-GPW-8501	WO-639992	PUMP, water, assembly	1	4.855
		H001-1013018	FM-20366-S	WO-6428	BOLT, hex-hd., S., 16-18NC-2 x 1/8	3	
		H001-7025711	FM-355442-S2	WO-51858	BOLT, hex-hd., S., 16-18NC-2 x 21/2	1	.0125
		3320-GPW-8524	FM-34806-S7	WO-51833	WASHER, lock, S., cd-pltd., SAE std., 5/16 in.	4	
		3320-GP W-8324	FM-GPW-8524	WO-639663	SEAL, water pump, assembly (superseded by SEAL, assembly, FM-GPW-8524-A,		
	01-4, 05-1	3320-GPW-8524-A	FM-GPW-8524-A	*****	WO-640031)	1 ,	.163
	01-4, 03-1	3320-GF W-8324-A	FW-GPW-8524-A	WO-640031	SEAL, water pump, assembly (also in KIT, FM-GPW-18515-B; KIT, WO-A-6839; FM-GPW-18515-C, WO-A-8774) (supersedes SEAL, assembly, FM-GPW-8524,		
					WO-639663)	. 1	
	05-1	3320-GPW-8576	FM-GPW-8576	WO-636298	SPRING, retaining, water pump bearing (also in KITS, FM-GPW-18515-B, WO-A-6839;	1	
			1 M G1 W-0070	VV O-030298	FM-GPW-18515-C, WO-A-8774)	1	
			FM-GPW-8572-B	WO-640033	SPRING, water pump seal	1	
			FM-GPW-8557		WASHER, water pump seal (superseded by WASHER, FM-GPW-8557-A, WO-640034)	1	
	01-4, 5	3320-GPW-8557-A	FM-GPW-8557-A	WO-640034	WASHER, water pump seal (also in KITS, FM-GPW-18515-B, WO-A-6839;	· 1	
					FM-GPW-18515-C, WO-A-8774) (supersedes WASHER, FM-GPW-8557)	1	
						. 1	
	i				0503A—FAN AND PULLEYS		
	01-2, 4	G503-7036577	FM-GPW-8600	WO-A-447	FAN, assembly (HI-88632)	1	.472
		H001-0121668	FM-20324-S2	WO-52168	BOLT, hex-hd., S., 1/4-20NC-2 x 5/8.	4	• 7 / 4
		G085-2102323	FM-34805-S2	WO-52706	WASHER, lock, S., SAE std., ¼ in.	4	
	01-5	3320-GPW-8509-A	FM-GPW-8509-A	WO-636299	PULLEY, fan and water pump.	1	.424
		3320-GPWS-8509	FM-GPW-8509		PULLEY, fan and water pump (Note 1).	i	

		·	WO-A-6701	WASHER, fan pulley shield retaining bolt (S., 1/4 I.D. x 9/16 O.D. x 0.005 thk.)	6	
· · · · ·				0503B—FAN BELT		
01-4	H017-0509226 H017-0509226	FM-GPW-8620 FM-GPW-8620-A	WO-A-1495 WO-A-9490	BELT, drive, fan and generator (superseded by BELT, FM-GPW-8620-A, WO-A-9490) BELT, drive, fan and generator (Goodrich Neoprene) (supersedes BELT,	1	.407
	H017-0507291	FM-GPWS-8620-S		FM-GPW-8620, WO-A-1495) BELT, drive, fan and generator (Note 1)	1	
	,	*		0505—ENGINE WATER FITTINGS AND HOSE		
	3320-60-8287	FM-60-8287	WO-52226	CLAMP, hose, 113/6 in. diam(ODD 111618) (MAC 2)	8	.0217
•	3320-GPW-8250	FM-GPW-8250 FM-24408-S	WO-A-1192 WO-52911	CLAMP, hose, 11% I.D., 2 slot, flat type (ORD 111618) (Note 2) ELBOW, engine cylinder head water outlet BOLT, hex-hd., S., 3/8-16NC-2 x 11/8	1 3	1.32
	H001-1518009 G503-0194030	FM-34807-S2 FM-GPW-8255	WO-5010 WO-639650	WASHER, lock, S., SAE std., 3/8 in GASKET, engine cylinder head water outlet elbow (also in GASKET SET,	3	
	G303-0194030	1 W-0233	W O-039030	FM-GPW-18387, WO-A-1537)	1 2	.0142
	G503-0217822	FM-GPW-8285	WO-A-6373	HOSE, radiator inlet, upper	2	.0391
	3320-GPW-8284	FM-GPW-8284	WO-A-592	HOSE, radiator water outlet, lower (1½ I.D. x 17% O.D. x 4¼ long)	1	.0551
75	G503-0217822 3320-GPW-8290	FM-IGT-8260 FM-GPW-8290	WO-630512 WO-A-6374	HOSE, radiator water outlet, upper (1½ I.D. x 1¾ O.D. x 2½ long)	1	.0425 .136

WO-A-1124

WO-A-1125

WO-636109

FM-GPW-8240 FM-35676-S

FM-GPW-8269

3320-GPW-8269

SHIELD, fan pulley 1
WASHER, fan pulley shield (S., $11\frac{1}{12}$ I.D. x $\frac{5}{8}$ O.D.) 6

TUBE, connecting, radiator water outlet.....

.261