

ALPHABETICAL INDEX

Description	Gov't Group	Description	Gov't Group
A			
Absorber, Shock—Assembly	1603	Door, Tail and Stop Lamp—Left	0608
Axle Assembly	1000	Door, Tail and Stop Lamp—Right	0608
B			
Body Assembly only—Painted	1800	Drum, Brake	1302
Body—Complete	1800	D	
Bolt, Cable Hook (Cable Equalizer)	1201	Eccentric, Brake Shoe	1203
Bolt, Divided Rim	1301	Equalizer, Cable	1201
Bolt, Hand Brake Lever Fulcrum (3/8"-24 thd. x 1" Special)	1201	Eye, Lunette	1506
Bolt, Safety Chain Eye	1506	Eyelet, 1/2"—No. 4 (Tarpaulin)	1800
Bolt, Spring Center	1601	E	
Bolt, Spring—Front	1602	F	
Bolt, Spring Shackle "U"—L.H. thd. (For Right Spring—Rear End)	1602	Fastener, Ring (Tarpaulin Tie Ropes)	1800
Bolt, Spring Shackle "U"—R.H. thd. (For Left Spring—Rear End)	1602	Fender Assembly	1701
Bolt, Wheel Hub—1/2"-20 L.H. thd.	1302	Fitting, Alemite Straight Grease	1602
Bolt, Wheel Hub—1/2"-20 R.H. thd.	1302	Fitting, Alemite—Straight—Threaded Drive Type	1506
Brace, Spring Pivot—Front	1506	G	
Bracket, Fender Anchor	1701	Gasket, Cover (For Blackout Light Switch)	0606
Bracket, Shock Absorber Mounting—Assembly	1800	Gasket, Wheel Flange	1302
Bracket, Spring Pivot—Front	1506	Grommet 13/32" (Wiring Harness thru cross member)	0606
Bracket, Support	1506	Grommet, 5/8" (Wiring Harness thru Side Member)	0606
Bracket, Tail Lamp—Left	1800	H	
Bracket, Tail Lamp—Right	1800	Handle, Plug	0606
Bracket and Brace, Left Spring Shackle—Assembly	1506	Handle and Sleeve, Plunger—Assembly	1506
Bracket and Brace, Right Spring Shackle—Assembly	1506	Harness, Trailer Wiring (4 Wires in Braided Loom)	0606
Bracket and Plunger, Draw Bar—Assembly	1506	Hook, (8 reqd. Tarpaulin Rope to Side Panels)	1800
Brake Assembly, Left	1200	(1 reqd. Tarpaulin Rope to Rear Panels)	1800
Brake Assembly, Right	1200	(2 reqd. Tarpaulin Rope to Front Panels)	1800
Bumper, Axle	1506	Housing, Assembly	0606
Bushing, Shock Absorber	1603	Housing Sub Assembly (Tail and Stop Lamp Body)	0608
Bushing, Spring Eye	1601	Hub Assembly	1302
Bushing, Spring Shackle—Assembly, L.H. thd. (For Right Spring—Rear End)	1602	Hub and Drum Assembly, L.H.	1302
Bushing, Spring Shackle—Assembly, R.H. thd. (For Right Spring—Frame End)	1602	Hub and Drum Assembly, R.H.	1302
Bushing, Spring Shackle—Assembly, R.H. thd. (For Spring and Frame—Rear End—Left)	1602	L	
Button, Hand Brake Lever Pawl Rod	1201	Lamp, Tail and Stop—Assembly, Left	0608
C			
Cable, Connector to Blackout Tail Light, Left Side	0606	Lamp, Tail and Stop—Assembly, Right	0608
Cable, Connector to Blackout Tail Light, Right Side	0606	Leaf, Spring—No. 1	1601
Cable, Coupling Socket—Assembly	0606	Leaf, Spring—No. 2	1601
Cable and Conduit Assembly	1201	Leaf, Spring—No. 3	1601
Cam, Brake Shoe Anchor Pin	1203	Leaf, Spring—No. 4	1601
Cap, Hub	1302	Leaf, Spring—No. 5	1601
Cap, Tire Valve	1301	Leaf, Spring—No. 6	1601
Chain, Safety	1506	Leaf, Spring—No. 7	1601
Channel, "A" Frame—Assembly	1506	Leaf, Spring—No. 8	1601
Clamp, Cable	0606	Leg, Support	1506
Clamp, "A" Frame—Left	1506	Lever, Brake—Assembly	1203
Clamp, "A" Frame—Right	1506	Lever, Hand Brake—Assembly, Complete	1201
Clip 1/4" (Connector to Blackout Tail Light—Left Side)	0606	Lining and Rivets, Brake Shoe—Service Package	1202
Clip, 3/16" (Connector to Blackout Tail Light—Left Side) (Trailer Wiring Harness to Body)	0606	Lockwasher, 1/2" Anchor Pin	1203
Clip, 1/16" (Trailer Wiring Harness to Body)	0606	Lockwasher, No. 8 Keyed	0606
Clip, 1/2" (3/32" Hole) (Coupling Socket Cable to "A" Frame Channel)	0606	Lockwasher, Outer Wheel Bearing Nut	1302
Clip, 5/8" (9/32" Hole) (Coupling Socket Cable to Draw Bar Bracket)	0606	N	
Clip, Conduit to Frame	1201	Nut, 1/16"-20 (For Spring Clip)	1000
Clip, Spring (Axle to Spring)	1000	Nut 1/2"-20 (For Rim Bolt)	1301
Clip, Spring—Large	1601	Nut 1/2"-20 (Left Hand Thread)	1302
Clip, Spring—Small	1601	Nut 1/2"-20 (Right Hand Thread)	1302
Cone and Roller Bearing	1302	Nut 7/8"-14	0606
Connector, 3-Wire Slip (Trailer Wiring Harness Extension to Blackout Tail Lamp Connector)	0606	Nut, Anchor Pin	1203
Crank, Hand Brake Bell	1201	Nut, Brake Disc Screw Nut	1200
Cup, Roller Bearing	1302	Nut, Draw Bar Eye Nut	1506
		Nut, Eccentric	1203
		Nut, Outer Wheel Bearing	1302

Description	Gov't Group	Description	Gov't Group
P			
Pawl, Hand Brake Lever.....	1201	Service Unit, Tail and Stop Lamp Upper—Assembly, Right.....	0608
Pin, Brake Shoe Anchor.....	1203	Service Unit, Tail and Stop Lamp Lower—Assembly....	0608
Pin, Clevis (Cable End to Cam Lever).....	1201	Shield, Dust.....	0606
Pin, Hand Brake Bell Crank Pivot.....	1201	Shoe and Lining Assembly, Forward—Brake.....	1202
Pin, Hand Brake Lever Pawl Rod.....	1201	Shoe and Lining Assembly, Reverse—Brake.....	1202
Plate, Backing—Assembly, Left.....	1208	Sleeve, Tire Mounting.....	1301
Plate, Backing—Assembly, Right.....	1208	Sleeve, Insulator.....	0606
Plate, Brake Shoe Anchor Pin.....	1203	Socket, Frame Draw Bar—Left.....	1800
Plate, Cover.....	0606	Socket, Frame Draw Bar—Right.....	1800
Plate, Instruction.....	1301	Spring Assembly (8 leaves).....	1601
Plate, Name.....	2202	Spring, Brake Shoe Return.....	1203
Plate and Shaft Assembly, Spring Clip—Left (On Right Spring).....	1000	Spring, Hand Brake Lever Pawl Rod.....	1201
Plate and Shaft Assembly, Spring Clip—Right (On Left Spring).....	1000	Spring, Lunette Eye.....	1506
Plug, Coupling Socket Cable.....	0606	Spring, Plunger (For Draw Bar Bracket).....	1506
R		Strut, Brake—Left.....	1203
Ratchet, Hand Brake Lever.....	1201	Strut, Brake—Right.....	1203
Reflector, Reflex.....	0608	Support, Body Drain Hole Valve.....	1800
Retainer, Spring Shackle Grease Seal.....	1602	Switch, Blackout Light.....	0606
Ring, Tire Bead Lock (16 x 6.00) (For .55 wide Tire Bead)	1301	T	
Rivet, Tubular for Brake Lining.....	1202	Tarpaulin Assembly, Complete.....	1800
Rod, Hand Brake Lever.....	1201	Terminal.....	0606
Rod, Hand Brake Lever Pawl.....	1201	V	
Rope, Tarpaulin Anchor Assembly.....	1800	Valve, Body Drain Hole—Assembly.....	1800
S		W	
Screw.....	0606	Washer, Plain.....	0606
Screw, Brake Disc.....	1200	Washer, Special.....	0608
Screw, Frame to Draw Bar Bracket.....	1506	Washer, Eyelet.....	1800
Screw, Safety Chain to Draw Bar Bracket.....	1506	Washer, Lunette Spring, Plain.....	1506
Screw, Support Leg to Support Brace.....	1506	Washer, Lunette Spring (Tongued).....	1506
Screw, Tail and Stop Lamp Door.....	0608	Washer, Outer Wheel Bearing.....	1302
Seal, Hub Oil—Assembly.....	1302	Washer, Special (For Shock Absorber).....	1603
Seal, Spring Shackle Grease.....	1602	Wheel, Divided Combat (16 x 4.50 Rim).....	1301
Seat, Drain Hole Ball.....	1800	Wheel, Inner Half Combat.....	1301
Service Unit, Tail and Stop Lamp Upper—Assembly, Left.....	0608	Wheel and Bolt Assembly, Outer Half Combat.....	1301